

Kabel	Zacisk	1XT1			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
b	A1	K1	1	Kb(ES1)	14	
	14	3Q	2	Kb(ES1)	11	
b			3			
b	1	2XT1	4	K1	13	
b	5	2XT1	5	3K	53	
b	6	2XT1	6	3K	54	
b	4	2XT1	7	K00.0	11	c2
b	7	2XT1	8	K00.0	14	c2
			9	3K	A1	
	74	3K	10	XS	1	c2
	22	K1	11	XS	2	c2
b	2	2XT1	12	XS	5	c2
b	3	2XT1	13	XS	66	c2
	21	K1	14	1XPS01	13	
	A2	3K	15	zacisk N		
b	13	2XT1	16			
b	11	2XT1	17	3K	84	
b	12	2XT1	18	K1	32	
	4	XF3	19	10K	63	
	5	XF3	20	10K	64	

Aparat	Oznaczenia	F2	3K												3Q			K1								Ks																			
	Typ lub nr schematu połączeń zewnętrznych	SCL6 B4	DIL4M/40DILM												NZM7			DILER-22 (230V; 50Hz)								DILER-22 (230V; 50Hz)																			
	Nr zacisku	1	2	A1	A2	63	64	83	84	53	54	73	74	13	14			T1	T2	T3	13	14	21	22	31	32	A1	A2							A1	A2	13	14							
połączenia dokład	Mostki, złącza uziemia																																												
	Nr zacisku			9	15	19	20			17	5	6		10		2						4		14	11		18	1																	
	Oznaczenie listwy lub aparatu		1XT1																																										
	Typ przewodu	DY 1,5																																											

Kabel	Zacisk	2XT1			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
b	4	1XT1	1	S4	8	
b	12	1XT1	2	S4	3	
b	13	1XT1	3	S4	4	
b	7	1XT1	4	S4	7	
b	5	1XT1	5	S3	13	
b	6	1XT1	6	S3	14	
b	8	1XT1	7	S3Q	22	
			8			
			9			
			10			
b	17	1XT1	11	H1	1	
b	18	1XT1	12	H2	1	
b	16	1XT1	13	H2	2	

Aparat	Oznaczenia		H1		S3		S3Q		H2		S4									
	Typ lub nr schematu połączeń zewnętrznych		M22-DL-G-X1				M22-DL-R-X0				Ł K15-2.829									
	Nr zacisku		1	2	13	14	21	22	1	2	1	2	3	4	5	6	7	8		
połączenia dokad	Mostki, złącza uziemia																			
	Nr zacisku		11		5	6		7	12	13			2	3			4	1		
	Oznaczenie listwy lub aparatu		2XT1																	
	Typ przewodu		DY 1,5																	