

Kabel	Zacisk	1XP3			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
	21	F3	1	Kb	34	
	16	FI	2	Kb	31	
b	9	2XP3	3	F3	T1	
b	1	2XP3	4	Ks	34	
b	5	2XP3	5	7K	53	
b	6	2XP3	6	7K	54	
b	4	2XP3	7	K00.2	11	c2
b	7	2XP3	8	K00.2	14	c2
			9	7K	A1	
	74	7K	10	XS	7	c2
	22	K1	11	XS	8	c2
b	2	2XP3	12	XS	9	c2
b	3	2XP3	13	1XP2	14	
	21	K1	14	1XM1	13	
	A2	7K	15	zacisk N		
b	13	2XP3	16			
b	11	2XP3	17	7K	84	
b	12	2XP3	18	K1	32	
b	10	2XP3	19	FI	Max	
	13	K1	20	Ks	31	
b	8	2XP3	21	F3	T2	

Aparat	Oznaczenia		F2		7K								7Q			K1								F3				FI				VF													
	Typ lub nr schematu połączeń zewnętrznych		SCL6 B4		DILOM/40DILM								PKZM			DILER-22 (230V; 50Hz)								EMT6				EMR4-N100-1-B				DS4340													
	Nr zacisku		1	2	A1	A2	63	64	83	84	53	54	73	74	1.13	1.14			T1	T2	T3	13	14	21	22	31	32	A1	A2	A1	A2	T1	T2	21	22	A1	A2	C	Max	15	16	A1	A2		
połączenia	Mostki, złącza uziemia																																												
	dokład	Nr zacisku																																											
		Oznaczenie listwy lub aparatu		1XP3																																									
		Typ przewodu		DY 1,5																																									

Kabel	Zacisk	2XP3			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
b	4	1XP3	1	S4	8	
b	12	1XP3	2	S4	3	
b	13	1XP3	3	S4	4	
b	7	1XP3	4	S4	7	
b	5	1XP3	5	S3	13	
b	6	1XP3	6	S3	14	
b	8	1XP3	7	S3Q	22	
b	21	1XP3	8	Ft(silnik P3)	1	
b	3	1XP3	9	Ft(silnik P3)	2	
b	19	1XP3	10	Ft(silnik P3)	elek.	
b	17	1XP3	11	H1	1	
b	18	1XP3	12	H2	1	
b	16	1XP3	13	H2	2	

Aparat	Oznaczenia	H1		S3	S3Q	H2		S4											
	Typ lub nr schematu połączeń zewnętrznych	M22-DL-G-X1				M22-DL-R-X0		ŁK15-2.829											
	Nr zacisku	1	2	13	14	21	22	1	2	1	2	3	4	5	6	7	8		
połączenia dokład	Mostki, złącza uziemia																		
	Nr zacisku	11		5	6		7	12	13			2	3			4	1		
	Oznaczenie listwy lub aparatu	2XP3																	
	Typ przewodu	DY 1,5																	