

Kabel	Zacisk	1XT2			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
b	A1	K1	1	Kb	14	
	14	10Q	2	Kb	11	
b			3			
b	1	2XT2	4	K1	13	
b	5	2XT2	5	10K	53	
b	6	2XT2	6	10K	54	
b	4	2XT2	7	K00.8	11	c2
b	7	2XT2	8	K00.8	14	c2
			9	10K	A1	
	74	10K	10	XS	17	c2
	22	K1	11	XS	18	c2
b	2	2XT2	12	XS	21	c2
b	3	2XT2	13	XS	67	c2
	21	K1	14	1XPS02	13	
	A2	10K	15	zacisk N		
b	13	2XT2	16			
b	11	2XT2	17	10K	84	
b	12	2XT2	18	K1	32	
	4	XF3	19	10K	63	
	5	XF3	20	10K	64	

Aparat	Oznaczenia		F2		10K										10Q						K1														Ks												
	Typ lub nr schematu połączeń zewnętrznych		SCL6 B4		DIL4M/40DILM										NZM7						DILER-22 (230V; 50Hz)														DILER-22 (230V; 50Hz)												
	Nr zacisku		1	2	A1	A2	63	64	83	84	53	54	73	74	13	14			T1	T2	T3	13	14	21	22	31	32	A1	A2							A1	A2	13	14								
połączenia	Mostki, złącza uziemia																																														
	dokad	Nr zacisku																																													
		Oznaczenie listwy lub aparatu		1XT2																																											
		Typ przewodu		DY 1,5																																											

Kabel	Zacisk	2XT2			Zacisk	Kabel
		Listwa lub aparat		Listwa lub aparat		
b	4	1XT2	1	S4	8	
b	12	1XT2	2	S4	3	
b	13	1XT2	3	S4	4	
b	7	1XT2	4	S4	7	
b	5	1XT2	5	S3	13	
b	6	1XT2	6	S3	14	
b	8	1XT2	7	S3Q	22	
			8			
			9			
			10			
b	17	1XT2	11	H1	1	
b	18	1XT2	12	H2	1	
b	16	1XT2	13	H2	2	

Aparat	Oznaczenia		H1		S3		S3Q		H2		S4										
	Typ lub nr schematu połączeń zewnętrznych		M22-DL-G-X1				M22-DL-R-X0				ŁK15-2.829										
	Nr zacisku		1	2	13	14	21	22	1	2	1	2	3	4	5	6	7	8			
połączenia	dokąd	Mostki, złącza uziemia																			